

How To Measure


These measuring instructions apply to all types of window coverings.

- For accurate measurements always use a metal tape measure
- Take measurements in millimetres
- Choose whether you want your blind to fit inside the recess of your window or hang outside the recess overlapping your window
- Always specify the width measurement first, followed by the drop

Recess

For blinds to hang inside the recess


- Measure the width of the window recess in the three places as shown in the diagram
- Measure the drop by taking the measurement from the top of the recess to the window sill, in three places as shown
- Always use the smallest measurement
- We will make all the necessary adjustments to ensure your blind fits perfectly



Blind Size

For blinds to hang outside the window

- Measure the exact area you would like the blind to cover as shown in the diagram below
- To minimise light leakage we recommend the blind overlaps by at least 50mm each side



For more information or help with fitting your blinds please call us 01862 842233 or email info@pvcverticalblinds.co.uk

